


Mechanical Splicer


Usage Instruction

- Thank you very much for purchasing and using this product.
- For using this product correctly, this instruction must be read carefully before usage.
- After reading, this instruction must be kept in convenient place for users' reading anytime.


The Product :



The Name :



Procedures :




According to the type of fiber, select if use 250Holder or not.
The 250Holder should be inserted into the Body from the smaller end.

Caution items:



- 1). Please select and use this product by the fiber specifications you need.
- 2). Ensure the implementing environment is within the scope of allowance.
- 3). Any problems caused by assembling which is not in accordance with the usage instrument will be been responsible for by the users.
- 4). The waste fiber is harmful to human's body and should be treated correctly.
- 5). Tools should be prepared by the users. The contents of the product do not involve this item.




2. Inert the 0.9mm fiber into the 0.9 head of the Body.



3. When meeting the end, push the Pusher.



5. Inset the 0.25mm fiber into the 0.25 head of the Body.



6. When meeting the end, push the Pusher.



7. Press the Cap and finish the job,

CERTIFICATION

INSPECTOR: _____
PRODUCT NO: _____
DATA: _____

